

Using ARM[®] your alarm company can verify that your entire security system is fully functional down to the last 'nut and bolt', giving you complete confidence and peace of mind in your security arrangements.

Secure and Convenient

- ARM enhances your security by constantly checking on the electrical status and functional capability of your alarm system.
- Regular reporting by your alarm system to the maintaining installation company takes the hassle out of service visits and ensures it is always operating at its peak performance level

Formal reporting

- At a pre-set time, the control panel will call the service desk and upload a full report on the status of your system. This report may be printed and copied to you, if required.

DD243 and EN50131

- ARM software incorporates the very best methodology to exceed the current police and European requirements on false alarm reduction and system functionality

You can view a demonstration of ARM by visiting www.arm2004.com

Detector performance analysis

- All detectors are regularly checked to ensure your complete protection. Regular reminders to walk-test the system are given

Full Signalling and Warning Analysis

- The correct operation of signalling equipment to the alarm receiving centre is reassured, along with a full test of the external sounders, initiated by the user

Full electrical analysis

- ARM will painstakingly check, day and night, that the wiring, mains and battery power, and auxiliary equipment are at the correct performance levels

total peace of mind

ARM[®]
automatic-remote-maintenance
inside

Your alarm system has ARM[®] Software installed in the Euro-MERiDIAN control panel.

technology that takes care of itself

Your alarm panel has been fitted with new Automatic Remote Maintenance (ARM®) software. This software will look after and monitor your alarm system every minute of every day to verify its integrity and ability to function correctly. From time to time you will be prompted to perform a simple test.



Test
System?

After every 70 times the system has been unset, it will prompt you to perform a brief test. The results of this test are stored in the panel and form part of the service report generated by the ARM maintenance computer.

To continue with the test, press **'YES'**.

(If you choose 'No' you will be asked again to perform the test the next time you unset your system. After rejecting the test three times you will not be asked to perform the test for another period of 70 system 'unsets')

Euro-MERiDIAN will test your outside siren and if appropriate, make a test call to your alarm receiving company.

You will then be asked to check if your most frequently used detectors are still operating correctly (see page F15 in your manual for more information)

To continue with the test, press **'YES'**.

Select All Areas, by pressing **'YES'**.



Walk Test
Areas [ABCD]



ARM Sounder
Test in Progress



Walk
Test?

Walk around the building and trip all of the detectors listed, including those on doors.

The system will 'chime' each time a detector responds. All detectors waiting to be tested will scroll in the display.

When all displayed detectors have been activated, the display will show 'Walk Test Completed'.

Now simply press **'NO'** and the ARM check is complete!

If it is not convenient to perform these steps when prompted, you may enter manager menu and perform a walk test and sounder test at a time to suit you (see page F1 in your user manual).



Walk Test
Completed



Walk
Test?